

GOLD TOP MACHINE GLAZE FOR THE ULTIMATE FINISH BY MACHINE

The Gold Top high performance glaze system for machine application provides a durable, high gloss, showroom finish whilst still allowing fresh paint to fully cure.

Finishing



- For use on all paint systems (fresh – well cured)
- Provides a long lasting high gloss finish
- Will withstand final car wash
- Does not dry up in use, even in direct sunlight so can work on large areas at a time
- Exhibits water repellent properties
- For machine application only

DIRECTIONS FOR USE ON REVERSE

Farécla[™]
automotive

GOLD TOP MACHINE GLAZE FOR THE ULTIMATE FINISH BY MACHINE

For best results follow these recommended steps:

- Shake the bottle of Gold Top Machine Glaze.
- Fit a Farécla Advanced G-Mop Polishing Foam to a polishing machine with a maximum free running speed 1500rpm.
- Apply a small amount of Gold Top Machine Glaze to the panel, spread on the panel surface using the face of the polishing foam before the machine is started.
- Start the machine and using light to medium pressure, polish to a durable high gloss finish.
- Should any residue remain, buff the surface with a clean and soft polishing cloth (Farécla Finishing Cloths are ideal).

PRODUCT	PART NUMBER	CASE QTY
Gold Top Machine Glaze 500ml	42008	12
Advanced G Mop Polishing Foam 8"	59012	6
Advanced G Mop Back Plate 8"	50015	6
Advanced G Mop Finishing Cloth 3 - pack	27019	12